COMPLETE 31 PCs Network Setup - Only PC31 Can Access Website

PART 1: ADDING ALL COMPONENTS

Step 1: Add All Devices to Workspace

- 1. Open **NEW** Cisco Packet Tracer file
- 2. Click on "End Devices" at bottom panel
- 3. Click on "PC" icon and click 31 times on workspace to add 31 PCs
 - Arrange them nicely (maybe 6 rows of 5 PCs each, plus 1 extra)
- 4. Click on "Server" icon and click once to add 1 Server
- 5. Click on "Network Devices" at bottom panel
- 6. Click on "Switches" folder
- 7. Click on "2960" switch and click twice to add 2 switches
- 8. Click on "Routers" folder
- 9. Click on "2811" router and click once to add 1 router

Step 2: Label Your Devices (Optional but Helpful)

- 1. Right-click each PC and rename them PC1, PC2, PC3... PC31
- 2. Rename switches to Switch1 and Switch2
- 3. Rename server to WebServer
- 4. Rename router to Router1

PART 2: PHYSICAL CONNECTIONS (VERY IMPORTANT - READ CAREFULLY)

Step 3: Connect First 22 PCs to Switch1

- 1. Click "Connections" → Select "Copper Straight-Through" cable (first cable)
- 2. Connect PCs to Switch1 as follows:
 - PC1 → Switch1 FastEthernet0/1
 - PC2 → Switch1 FastEthernet0/2
 - PC3 → Switch1 FastEthernet0/3
 - PC4 → Switch1 FastEthernet0/4
 - **PC5** → Switch1 **FastEthernet0/5**
 - PC6 → Switch1 FastEthernet0/6
 - **PC7** → Switch1 **FastEthernet0/7**

- PC8 → Switch1 FastEthernet0/8
- PC9 → Switch1 FastEthernet0/9
- PC10 → Switch1 FastEthernet0/10
- PC11 → Switch1 FastEthernet0/11
- PC12 → Switch1 FastEthernet0/12
- PC13 → Switch1 FastEthernet0/13
- PC14 → Switch1 FastEthernet0/14
- PC15 → Switch1 FastEthernet0/15
- PC16 → Switch1 FastEthernet0/16
- PC17 → Switch1 FastEthernet0/17
- PC18 → Switch1 FastEthernet0/18
- PC19 → Switch1 FastEthernet0/19
- PC20 → Switch1 FastEthernet0/20
- PC21 → Switch1 FastEthernet0/21
- PC22 → Switch1 FastEthernet0/22

Step 4: Connect Remaining 9 PCs to Switch2

- 1. Still using "Copper Straight-Through" cable
- 2. Connect remaining PCs to Switch2:
 - PC23 → Switch2 FastEthernet0/1
 - PC24 → Switch2 FastEthernet0/2
 - PC25 → Switch2 FastEthernet0/3
 - PC26 → Switch2 FastEthernet0/4
 - PC27 → Switch2 FastEthernet0/5
 - PC28 → Switch2 FastEthernet0/6
 - PC29 → Switch2 FastEthernet0/7
 - PC30 → Switch2 FastEthernet0/8
 - PC31 → Switch2 FastEthernet0/9 ← THIS IS OUR TARGET PC!

Step 5: Connect Switch1 to Switch2 (Inter-Switch Link)

- 1. Using "Copper Straight-Through" cable
- 2. Switch1 FastEthernet0/23 → Switch2 FastEthernet0/23

Step 6: Connect Switch1 to Router

- 1. Using "Copper Straight-Through" cable
- 2. Switch1 FastEthernet0/24 → Router FastEthernet0/0

Step 7: Connect Server to Router

- 1. Using "Copper Straight-Through" cable
- 2. Server FastEthernet0 → Router FastEthernet0/1

PART 3: CONFIGURING IP ADDRESSES

Step 8: Configure All 31 PCs

Configure each PC with Static IP as follows:

PC1:

- Click PC1 → Desktop → IP Configuration → Static
- IP Address: (192.168.1.1)
- Subnet Mask: (255.255.255.0)
- Default Gateway: 192.168.1.254

PC2:

- Click PC2 → Desktop → IP Configuration → Static
- IP Address: (192.168.1.2)
- Subnet Mask: (255.255.255.0)
- Default Gateway: (192.168.1.254)

Continue this pattern for ALL PCs:

- PC3: IP = (192.168.1.3)
- PC4: IP = (192.168.1.4)
- PC5: IP = (192.168.1.5)
- PC6: IP = (192.168.1.6)
- PC7: IP = (192.168.1.7)
- PC8: IP = (192.168.1.8)
- PC9: IP = (192.168.1.9)
- PC10: IP = (192.168.1.10)
- PC11: IP = (192.168.1.11)
- PC12: IP = (192.168.1.12)

- PC13: IP = (192.168.1.13)
- PC14: IP = (192.168.1.14)
- PC15: IP = (192.168.1.15)
- PC16: IP = (192.168.1.16)
- PC17: IP = (192.168.1.17)
- PC18: IP = (192.168.1.18)
- PC19: IP = (192.168.1.19)
- PC20: IP = 192.168.1.20
- PC21: IP = (192.168.1.21)
- PC22: IP = 192.168.1.22
- PC23: IP = (192.168.1.23)
- PC24: IP = (192.168.1.24)
- PC25: IP = 192.168.1.25
- PC26: IP = (192.168.1.26)
- PC27: IP = (192.168.1.27)
- PC28: IP = (192.168.1.28)
- PC29: IP = (192.168.1.29)
- PC30: IP = (192.168.1.30)
- PC31: IP = (192.168.1.31) ← SPECIAL PC

For ALL PCs, use same Subnet Mask and Gateway:

- Subnet Mask: (255.255.255.0)
- Default Gateway: (192.168.1.254)

Step 9: Configure Server

- 1. Click Server \rightarrow Desktop \rightarrow IP Configuration \rightarrow Static
- 2. IP Address: (192.168.2.10)
- 3. Subnet Mask: (255.255.255.0)
- 4. Default Gateway: (192.168.2.1)

PART 4: CONFIGURE ROUTER

Step 10: Configure Router Interfaces

1. Click Router → CLI tab

- 2. Press Enter when prompted
- 3. Type these commands **EXACTLY**:

```
enable
configure terminal
interface fastethernet 0/0
ip address 192.168.1.254 255.255.255.0
no shutdown
exit
interface fastethernet 0/1
ip address 192.168.2.1 255.255.255.0
no shutdown
exit
```

PART 5: SETUP WEB SERVER

Step 11: Enable HTTP Service

- 1. Click Server → Services tab
- 2. Click HTTP from left menu
- 3. Make sure HTTP Service is ON
- 4. Leave default webpage content (or customize if you want)

PART 6: TEST BEFORE RESTRICTION

Step 12: Test Basic Connectivity (Optional)

- 1. Pick any PC (like PC15):
 - PC15 → Desktop → Web Browser
 - URL: (192.168.2.10)
 - Should load the webpage
- 2. Try PC31:
 - PC31 → Desktop → Web Browser
 - URL: (192.168.2.10)
 - Should also load the webpage

At this point, ALL PCs can access the website. Next we'll restrict it.

PART 7: CREATE ACCESS RESTRICTION

Step 13: Configure Access Control List (ACL)

1. Click Router → CLI tab

2. Type these commands **EXACTLY**:

```
configure terminal
access-list 100 permit tcp host 192.168.1.31 host 192.168.2.10 eq 80
access-list 100 deny tcp 192.168.1.0 0.0.0.255 host 192.168.2.10 eq 80
access-list 100 permit ip any any
interface fastethernet 0/0
ip access-group 100 in
exit
exit
write memory
```

PART 8: FINAL TESTING

Step 14: Test PC31 (Should Work)

- 1. Click **PC31**
- 2. Desktop → Web Browser
- 3. URL: (192.168.2.10)
- 4. Press Enter
- 5. RESULT: Website should load successfully

Step 15: Test Other PCs (Should be Blocked)

Test PC1:

- 1. Click PC1 → Desktop → Web Browser
- 2. URL: (192.168.2.10)
- 3. RESULT: Should NOT load (blocked) X

Test PC15:

- 1. Click PC15 → Desktop → Web Browser
- 2. URL: (192.168.2.10)
- 3. RESULT: Should NOT load (blocked)

Test PC30:

- 1. Click PC30 → Desktop → Web Browser
- 2. URL: (192.168.2.10)
- 3. RESULT: Should NOT load (blocked) X

SUMMARY OF CONNECTIONS

Switch1 (22 PCs + Links):

• Ports 0/1 to 0/22: PCs 1-22

• Port 0/23: Connected to Switch2

• Port 0/24: Connected to Router

Switch2 (9 PCs + Link):

• Ports 0/1 to 0/9: PCs 23-31

Port 0/23: Connected to Switch1

Router:

• **FastEthernet 0/0:** Connected to Switch1 (IP: 192.168.1.254)

• **FastEthernet 0/1:** Connected to Server (IP: 192.168.2.1)

Final Result:

- Only PC31 can access the website
- X PCs 1-30 are blocked from the website
- All PCs can still ping each other and communicate normally

TROUBLESHOOTING

If PC31 doesn't work:

- Check PC31 IP is exactly (192.168.1.31)
- Verify HTTP service is ON in server
- · Check all cables are connected

If other PCs still work:

- Verify ACL commands were typed exactly
- Check ACL is applied to correct interface (FastEthernet 0/0)
- Type show access-lists in router CLI to verify ACL exists

Connection problems:

- Wait 30 seconds after configuration
- Check all port lights are green
- Verify no port conflicts in connections